



# ISKRA MT173

If your RM number is 649 or 552 this is the meter type you may have. The RM number is located at the bottom left hand side of the meter. This meter may have an auto scroll feature that changes screens automatically. Press the button only if the meter has no auto scroll.

- |   |  |                                     |    |  |  |
|---|--|-------------------------------------|----|--|--|
| 1 |  | Current Date<br>(dd.mm.yy)          | 8  |  | MD2 Occurred End<br>Time (hh:mm:ss)              |
| 2 |  | Current Time<br>(hh:mm:ss)          | 9  |  | Rising Demand<br>(% 15min Elapsed<br>-- 0.000kW) |
| 3 |  | MD1 Normal kW<br>(08:00-21:00 GMT)  | 10 |  | Day kWh (08:00-<br>23:00 GMT)                    |
| 4 |  | MD1 Occurred Date<br>(dd.mm.yy)     | 11 |  | Night kWh (23:00-<br>08:00 GMT)                  |
| 5 |  | MD1 Occurred End<br>Time (hh:mm:ss) | 12 |  | Total Q1 Reactive<br>kVArh                       |
| 6 |  | MD2 Peak kW<br>(17:00-19:00 GMT)    | 13 |  | Total 24hr kWh                                   |
| 7 |  | MD2 Occurred Date<br>(dd.mm.yy)     | 14 |  | Back to Display 1                                |